

enduralex[®]

COLLECTION	Contract Vinyl Upholstery Collection
WIDTH	137cm
SUITABLE APPLICATIONS	Contract Upholstery Vinyl
MARKET SECTOR	Healthcare, Leisure
ABRASION	enduralex[®] Contract materials have been surface abrasion tested to BS EN ISO 12947-2:1999 as modified by Annex A of BS EN 14465:2003 and to BS 5690:1991:Annex F of BS 2543:1995 when they exceeded the requirement for 'Severe Contract' in accordance with the Martindale Abrasion Test.
FLAMMABILITY	BS582 :1990 :Section 4 :Ignition. Source 5 (Crib):tested with CMHR foam
FEATURES	<ul style="list-style-type: none"> • Meets the physical specification BS 5790 part 1:type 2:Grade X:1996 and ISO 7617-1:1994E • enduralex[®] Contract fabrics are manufactured with UV stabilised pigments giving enhanced protection against harmful UV rays and equivalent to 4 plus on the 'grey scale'. • These materials are formulated with an anti-bacterial/anti microbial additive to resist and repel most known bacteria from developing on its surface, and are equally effective in repelling growth of the E-coli and MRSA bacteria (test results available on request).
CLEANING RECOMMENDATION	<p>enduralex[®] Contract materials are protected by 'Produractec-C'[®] lacquer coating and are resistant to every day wear and contact with mild acids, alkali, drinks, household stains.</p> <ul style="list-style-type: none"> • Use warm soapy water and/or Haz-tab or Clor-clean solution and a household cloth • Rub evenly in the direction of the grain of the material • Rinse with clean water afterwards • Can also be steam cleaned <p>DO NOT USE bleaches, solvents, abrasives, wax polishes or aerosol sprays.</p>

WHILST EVERY EFFORT AND CARE IS MADE TO ENSURE YOUR ORDER WILL MATCH THE SAMPLES SHOWN IN THE PATTERN BOOK, AN EXACT MATCH CANNOT BE GUARANTEED.

"enduralex"[®] and "Produractec"[®] are the European registered intellectual property of CGPC Group
 UK Distributor: Fabercon Ltd, Riven House, Fairview Road, Weyhill, Andover, Hants. SP11 0ST